Enable Quick Alarm of Liquid Leak at Every Industrial Field Site, even Ultra-DI Water, with Lower Cost, Easier Setting-up and Helps for Better Reliable Alert System


CE Mark Compliance (É
UL Recognized Products
EU-RoHS Compliance RoHS

Leak Sensor

RS-1000 RS-2000

Series






■BASIC STRUCTURE AND DETECTION PRINCIPLES

The detection unit consists of an infrared LED, photodiode, absorbent paper and a bracket (The no-paper use type does not use an absorbent paper).

At the Normal Status, the infrared light is reflected off the surface of the white absorbent paper back to the photodiode Chart (1). When a leak occurs, the absorbent paper absorbs the leaking liquid getting its color to be transparent, as it becomes wet, namely the paper passes the light through it to the other side of the paper.

As a result, the reflecting light energy of infrared light shrinks less than that is reflected when the paper color is white before wet. The photodiode converts the both of light energy by electric potential energy to deliver into the circuit. Then the sensor can process such change of electric potential by the liquid detection status for making the alert.(2).



■ MODEL REFERENCE

Detection Units	Combination Ty Standard	<u>pe</u>	Standalone Type	· · · · · · · · · · · · · · · · · · ·	ombination Type ail-Safe Concept
For General Liquid·····	·· RS-1000D		RS-1000DA-24V		RS-2000D
*(Paperless Sensor)·········	·· RS-1000PN		RS-1000DAP		RS-2000DP
For General Liquid	·· RS-1000P		RS-1000PA-24V		RS-2000P
*(Paperless Sensor)	RS-1000PP		RS-1000PAP		RS-2000PP
For Corrosive Acid, etc ·····	·· RS-1000F		RS-1000FA-24V		RS-2000F
*(Paperless Sensor) ·········	·· RS-1000FP		RS-1000FAP		RS-2000FP
	Combine Use	e In	dependent Use	e Co	mbine Use
Control Units	4			•	
Input/Output port: 1·····	RS-1000C		N/A		RS-2000C
Input/Output port: 8	RS-1000CA		N/A		RS-2000CA

^{*&}quot;Paperless Sensor" can be used without absorbent paper. These models are prepared for certain application, which is not convenient to maintain the paper replacing. Still, the absorbent paper is good for detecting the liquid very quick by a fine bit of a drip of the liquid. You can choice either sensor configuration from the above listed products to fit with your conditions and application.


Brackets	Absorbent Paper
Stainless steel bracket·····	Clean Paper P/N-6411(-R) P/N-6417
PVC Bracket with 3mm diameter screw holes ·····	P/N-6418
PVC Bracket with 4mm diameter screw holes ·····	P/N-6419
Exclusive use with RS-1000PN ·····	P/N-6414
SST bracket for Paperless sensor (except RS-1000PN)······	P/N-6416
PVC Bracket for Paperless sensor (except RS-1000PN)	P/N-6420B
100 MV 100 MV 100	

□SYSTEM CONFIGURATION

The RS-1000 series leak sensor has the combination type of models they are consisted with the Control Unit and the Detection Unit. The Control Unit of RS-1000 series has two different models by the number of input/output.


RS-1000C

A maximum of 10 Detection Units can be connected to one input terminal at a time in a Control Unit. One output is provided by a relay contact, single pole.



RS-1000CA

A maximum of 8 Detection Units can be connected to 8 independent input terminals individually. 8 independent outputs are provided, and each is allotted to an individual input.



SPECIFICATIONS Control Unit

	RS-1000C	RS-1000CA			
Input Voltage	24VDC ± 10%				
Power Consumption	150mA below	200mA below			
Light of Leak Indicator (Red)	On: Leakage Alarm Off: Normal Status				
Relay Contact Output *	Normally open x 1 pole	Normally Open x 8 poles, independer			
Ambient Temperature	-10 ~ 60 deg C (1	4 ~ 140 deg F)			
Capacity of Relay Contact (Max)	24VDC, 1A (res	sistance load)			
Case Material	ABS Resin				
Weight	90g	300g			

^{*}NC contact is available for RS-1000C and RS-1000CA, when the ordering designation code is followed by –NC after the above model number. e.g. RS-1000C-NC, RS-1000CA-NC.)

Detection Unit

Detecti	on one	DC 4000D	DC 4000E	DC 4000D	DC 4000DN	DC 4000ED	DC 4000DD
CAL STRUCTURE		RS-1000D	RS-1000F	RS-1000P	RS-1000PN	RS-1000FP	RS-1000PP
Supply Voltage	pply Voltage 5VDC±5%						
Power Consu	mption			20mA	below		
Indication LED	(Red/ Green)		Red:	Leakage Alarm,	Green: Normal S	Status	
Ambient Temp	erature		-1	$0\sim 60\deg C$	(14 \sim 140 deg	F)	
Connection wi	ith Control Unit	All D	etection Unit mu	st be used with I	RS-1000C or RS-	1000CA Control	Unit.
	Case	PVC	PFA	PP	PVC	PFA	PP
Material	Cable	HT-PVC	FEP	HT-PVC	HT-PVC	FEP	HT-PVC
Material	LED	Ероху	Ep	оху	Ероху	Ероху	
	Lamp	(exposed)	(embe	edded)	(exposed)	(embedded)	
Mater Dretest		Silicon	Sealed,		Silicon	Sealed,	
Water Protect		Stuffed	Silicon	Stuffed	Stuffed	Silicon Stuffed	
Weight		40g	5	5g	40g	55g	
Absorbent Pa	Paper Required Not Required						
Selectable Bra	electable Bracket P/N-6417, P/N-6418, P/N-6419 P/N-6414 P/N-6416, P/N			P/N-6420B			


^{*}RS-1000P Detector can be supplied with the teflon cable in stead of PVC cable per request. The Model is RS-1000P-FC-6417 provided with the Bracket P/N-6417. All the features of the sensor are quite the same as RS-1000P with PVC cable.

^{*}Please refer the next page for specification of the Bracket and the Absorbent Paper.

□WIRING INSTRUCTION

Generally 3-core shielded cable is supplied with the Body. Connect the correct power source to Red line and Shield.

- Avoid wrong wiring for the polarity of DC power. Red line for PLUS polarity, and Shield for MINUS.
- Keep the load current not exceeding 50mA. Unless, the output circuit of Sensor may be damaged.
- When you apply an inductive load, add a diode into output connection in parallel configuration in order to limit the back electromotive voltage for protecting the circuit.



□ SPECIFICATIONS

		RS-1000DA -24V	RS-1000FA - 24V	RS-1000PA -24V	RS-1000DAP	RS-1000FAP	RS-1000PAP
Supply Voltage	е		7a	5VDC(-5%) to	o 24VDC(+5%)		=
Power Consu	mption			20m/	below		
Indication of L	ED			Red: Leakage	Green: Normal		
Output			NPN Transi	istor Open Collec	ctor 50mA, 2 oppo	osite signals	
Ambient Temp)	-10 \sim 60 deg C (14 \sim 140 deg F)					
10.	Case	PVC	PFA	PP	PVC	PFA	PP
Meterial	Cable	HT-PVC	FEP	HT-PVC	HT-PVC	FEP	HT-PVC
Material La	Lamp	Epoxy (exposed)	Epoxy (embedded)		Epoxy (exposed)	Epoxy (embedded)	
Water Protect Silicon Sealed, Stuffed Silicon Stuffed			Silicon Stuffed	Sealed, Silicon Stuffed			
Weight		45g	55g		45g	55g	
Absorbent Pa	per	3	Required		Not Required		
Selectable Bra	acket	P/N-64	17, P/N-6418, P/	/N-6419	P/N-6416, P/N-6420B		

□ ACCESSORIES Bracket

	P/N-6417	P/N-6418	P/N-6419	P/N-6414	P/N-6416	P/N-6420B
Material	SUS301	PVC	PVC	SUS301	SUS301	PVC
Remarks	Nickel Plated	3mm Diameter	4mm Diameter	RS-1000PN	For Paperless sensors,	
Remarks	Nicker Flated	Screw Holes	Screw Holes	Use only	except RS-1000PN	

Absorbent Paper

	P/N-6411(-R)
Material	Clean Paper
Remarks	Content: 100 pieces in a pack. Supplied for a spare stock.
	(10 pieces are supplied with each detection unit.)

□ SYSTEM CONFIGURATION

The RS-2000 series leak sensor consists of the Control Unit and the Detection Unit that has RS-2000 designation. RS-2000C RS-2000CA A Control Unit operates one Detection A Control Unit allows connecting up to 8 Detection Units to each Unit. It has a relay contact that works individual terminal separately. It has 8 relay outputs corresponding to when Leakage has occurred. each Detection Unit and another relay output that alarms on Failure. Power Source Relay Out for Leakage Power Source (24VDC) (24VDC) #1~8 Relay Out for Failure Control Unit Relay Out **Detection Unit** Detection Unit #1 Detection Unit #8

NOTE: The RS-2000 series control unit does not allow connecting 2 or more Detection Units to one terminal by parallel connection.

□ SPECIFICATIONS

Control Unit

		RS-2000C			RS-2000	OCA
Input Voltage		24VDC ± 10%				
Power Consum	ption	100mA below			200mA b	elow
	LED for Leakage	Red: Leakage, Fa	ilure Greer	n: Normal	Off: Power (Outage
Leak Indicator	LED for Failure	Red: Failure		Off: Norm	nal	
Discriminative D	Detection		Ye	s		
Ambient Temp.		-10 \sim 60 deg C (14 \sim 140 deg F)				
Number of Inpu	t for Detection Unit	1 8				
Max Detection l	Jnit per Input		1			
Relay Contact	Numbers	1		9 (8 for Leakage 1 for F		1 for Failure)
Outputs	Capacity		24VDC 1A (res	resistance load)		***
17FCN	Status	Normal: Close Lea	akage/Failure Al	arm: Open	Power O	utage: Open
Case Material		ABS Polymer				
Weight		100g		330g		

Detection Unit

Detet	ction Unit						
		RS-2000D	RS-2000F	RS-2000P	RS-2000DP	RS-2000FP	RS-2000PP
Supply Volta	ge			5VDC	± 5%		
Power Cons	umption			20mA	below		
Indication of	LED		Red: L	eakage Green	n: Normal Off:	Failure	
Connection v	with Control Unit	All D	etection Unit mu	st be used with I	RS-2000C or RS-	2000CA Control	Unit.
Ambient Tem	ıp.		-1	$0\sim 60\deg C$	(14 \sim 140 deg	F)	
7/5	Case	PVC	PFA	PP	PVC	PFA	PP
Material	Cable	HT-PVC	FEP	HT-PVC	HT-PVC	FEP	HT-PVC
Material	LED Lamp	Epoxy (exposed)	Epoxy (embedded)		Epoxy (exposed)	Epoxy (embedded)	
Water Protect		Silicon Stuffed	Sealed, Silicon Stuffed		Silicon Stuffed	Sealed, Silicon Stuffed	
Weight		40g	55g		40g	55g	
Absorbent Paper			Required		Not Required		
Selectable Bracket		P/N-6417, P/N-6418, P/N-6419			P/N-6416, P/N-6420B		

Please refer the next page for more details for the condition of the LED and Relay Contacts.

☐THE ADDITIONAL FEATURES ON RS-2000 SERIES

RS-2000 has unique features that can detect any failure listed below.

- 1) Improper wiring between Control Unit and Detection Unit
- 2) Power outage of Control Unit
- 3) Broken wiring connected with Control Unit (7 different wiring should be connected with Control Unit.)
- 4) Power outage of Detection Unit
- 5) Decline of the IR LED inside the Detection Unit

RS-2000 series detects above failure and alarms by relay out when any failure has occurred. RS-2000 has second LED that indicates "Failure" to alarm failure status as above other than leakage alarm. In order that, RS-2000CA has second Relay Contact that works only when failure (except leakage) has occurred. In case of RS-2000CA, it is available to design the system that distinguishes between leakage and failure automatically.

Please note that RS-2000CA has a Dip Switch that disables detecting circuit to prevent un-required alarm when the number of using Detection Units is below 8. Please refer the Operation Manual for the details of the Dip Switch.

☐DESCRIPTIONS of the STATUS of LED & RELAY CONTACTS RS-2000CA


				LED on	LED on Co	ontrol Unit	Relay	/ Out
				Detection Unit	for Leakage	for Failure	for Leakage	for Failure
Normal C	ondition			Green	Green	Off	Close	Close
Leak Con	dition			Red	Red	Off	O Open	Close
Dip switch	h Off		ļ.	N/C	Off	Off	O Open	Close
Improper	Wiring of	Detection	on Unit	Depending on situation	Red	Red	O Open	O Open
Broken W	iring on I	Power Li	ne	Off	Off	Off	O Open	O Open
Broken W	liring of F	Relay Ou	t	Green	Green	Off	See NOT	E below.
Broken W	/iring of D	Detection	Unit			S	1A (4)	
	+5V			Off	Red	Red	O Open	O Open
		SIG		Green	Red	Red	O Open	O Open
Broken		5	GND	Off	Red	Red	O Open	O Open
Wiring	+5V	SIG		Off	Red	Red	O Open	O Open
vviilig		SIG	GND	Off	Red	Red	O Open	O Open
	+5V		GND	Off	Red	Red	O Open	Open
	+5V	SIG	GND	Off	Red	Red	O Open	O Open
Short Circ	cuit on De	etection I	Jnit					
cooper peri	+5V	SIG		Green	Red	Red	Open	O Open
Short		SIG	GND	Green	Red	Red	O Open	O Open
Circuit	+5V		GND	Off	Red	Red	O Open	O Open
	+5V	SIG	GND	Off	Red	Red	O Open	O Open
Power Ou	utage of C	Control U	nit	Off	Off	Off	O Open	O Open
Power Ou	utage of D	Detection	Unit	Off	Red	Red	O Open	O Open
Decline o	f the IR L	.ED		Red	Red	Off	O Open	Close

RS-2000C

				LED on	LED on Control Unit		Relay Out
				Detection Unit	for Leakage	for Failure	for Leakage
Normal C	ondition			Green	Green	Off	● Close
Leak Con	dition			Red	Red	Off	O Open
Improper	Wiring of	Detection	on Unit	Depending on situation	Red	Red	O Open
Breaking	Wiring or	Power	Line	Off	Off	Off	O Open
Breaking				Green	Green	Off	See NOTE below.
Breaking							
	+5V			Off	Red	Red	O Open
		SIG		Green	Red	Red	O Open
D1			GND	Off	Red	Red	O Open
Break	+5V	SIG		Off	Red	Red	O Open
Wiring		SIG	GND	Off	Red	Red	O Open
	+5V		GND	Off	Red	Red	O Open
	+5V	SIG	GND	Off	Red	Red	O Open
Short Circ	uit on De	tection l	Jnit				
	+5V	SIG		Green	Red	Red	O Open
Short		SIG	GND	Green	Red	Red	O Open
Circuit	+5V		GND	Off	Red	Red	O Open
	+5V	SIG	GND	Off	Red	Red	O Open
Power Outage of Control Unit		nit	Off	Off	Off	O Open	
Power Ou				Off	Red	Red	O Open
Decline of the IR LED				Red	Red	Off	O Open

NOTE: When the wiring for relay out gets broken, it will be noticed by cutoff of the loop for the relay out, though relay does not work. However, when there is short circuit on the wiring for relay out, it is impossible to be noticed by this sensor system.

□ DIMENSIONS



DUE TO CONTINUOUS PRODUCT IMPROVEMENT, THE DESIGN AND TECHNICAL SPECIFICATIONS ARE SUBJECT TO CHANGE WITHOUT PRIOR NOTICE.

TASHIKA CO., LTD.

1-12, Kaiyo-cho, Ashiya, 659-0035, JAPAN

Tel: +81-797-23-9035 Fax: +81-797-23-2105

e-mail: sales@tashika.co.jp URL: www.tashika.co.jp